

BEARING TYPE		BORE SIZE IN INCHES																												
Cross Section		1.00	1.50	1.75	2.00	2.50	3.00	3.50	4.00	4.25	4.50	4.75	5.00	5.50	6.00	6.50	7.00	7.50	8.00	9.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	25.00	30.00	
CAA Series	A	▲	▲	▲																										
	C	▲	▲	▲	✓																									
	X	▲	▲	✓																										
JHA Series	A																													
	C	▲	▲	▲																										
	X	▲	▲	▲																										
KA Series	A				▲	▲	▲	▲		✓	✓		▲	✓	✓				✓											
	C				▲	▲	▲	▲		✓	✓	✓	▲	✓	▲	✓	✓	✓	✓	✓	✓			✓						
	X				▲	▲	▲	▲		✓	✓	✓	▲	▲	▲	✓	✓	✓		✓	✓			▲						
**JA Series	A																													
	C				▲	▲	▲	▲	▲	▲			✓	✓	✓															
	X				▲	▲	▲	▲	▲	✓			✓	✓	▲															
KB Series	A				▲	✓	✓	▲	✓				✓	✓																
	C				▲	✓	✓	✓	✓	✓			✓		✓	✓					✓									
	X				✓	✓	✓	✓	▲	▲	✓		✓	✓	✓	✓				✓	✓									
**JB Series	A																													
	C				▲	▲	▲	▲	▲	▲			✓	✓	✓															
	X				▲	▲	▲	▲	▲	▲			✓	✓	✓															
**JU Series	A																													
	C								✓		▲	▲	▲	▲	▲	▲	✓	▲	▲	▲	▲	▲	✓	✓						
	X								▲		▲	✓	▲	▲	✓	▲		▲	✓	✓	▲	▲	✓	✓						
KC Series	A								✓		✓		▲		✓															
	C								▲		▲		✓	✓	✓	✓	▲	✓			✓	▲	✓	✓						
	X								✓		▲		✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	▲	✓	✓			
KD Series	A								▲	✓	✓		✓	✓	✓	✓	✓		✓	▲		✓								
	C								▲	✓	✓		▲	✓	▲	✓	▲	✓	▲	✓	✓	✓	✓	▲	✓	✓				
	X									✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	▲	✓	▲	▲	✓	✓			
KF Series	A												✓	✓	▲		▲	✓	✓		▲				✓					
	C								✓			✓	✓	✓	▲	✓	✓	▲	✓	▲	✓	▲	▲	▲	▲	▲				
	X								✓			✓	✓	▲	✓	✓	✓	✓	✓	✓	✓	▲	▲	▲	▲	✓				
KG Series	A															▲					✓			▲	✓	▲	✓	▲		
	C												✓		✓	▲	✓	▲	▲	▲	▲	▲	✓	▲	▲	▲	✓	✓	▲	▲
	X												✓		▲	▲	▲	✓	▲	✓	▲	✓	▲	▲	▲	▲	▲	✓	✓	

LOAD CONDITION						
Bearing Type	Contact	Radial	Axial	Moment	Reversing Axial	Combined Radial-Thrust
A	Angular	Good	Excellent	Do Not Use	Do Not Use	Good
C	Radial	Excellent	Good	Good	Good	Good
X	4-Point	Fair	Good	Excellent	Excellent	Fair